
# **Understanding TCP/IP Properties**

#### 1. Objectives

- ▶ Use of IP address, Subnet mask, Default gateway, MAC address.
- ➤ Identify tools used to discover a **computer network configuration** in Windows.
- > Gather information including **connection**, **host name**, **MAC address** and **IP address** information.
- **Compare** network information to other PCs on the network.
- Learn to use the **TCP/IP Packet Internet Groper (ping) command** from a workstation/PC.

#### 2a. IP address, Subnet mask, Default gateway, MAC address

Consider the following diagram:




- i. Write down the subnet mask:
- ii. Find the **network portion** of the IP address of the Gateway Machine:....
- iii. Is the default gateway (Gateway Machine's IP address) same for all the Workstations (PCs)?.....
- iv. Find the **default gateway** for the Workstations (PCs):

#### 2b. Crossover and Straight-through Cables

Common Ethernet network cables are straight and crossover cable. This Ethernet network cable is made of **4 pair high performance cable** that consists of **twisted pair conductors** that used for data transmission. Both end of cable is called **RJ45 connector**. Straight and crossover cable can be Cat3, Cat 5, Cat 5e or Cat 6 UTP cable, the only difference is each type will have different wire arrangement in the cable for serving different purposes.



# Category 1 (Layer 2 or below) Hub Switch



You usually use **straight cable** to connect **different type of devices (different category)**. For example:

- ✓ Connect a computer to a switch/hub's normal port.
- ✓ Connect a router's LAN port to a switch/hub's uplink port. (normally used for expanding network)

Use crossover cable to connect same type of devices (same category). For example:

- ✓ Connect 2 computers directly.
- ✓ Connect a router's LAN port to a switch/hub's normal port. (normally used for expanding network)
- ✓ Connect 2 switches/hubs by using normal port in both switches/hubs.

## Computer Networks Laboratory **Lab Experiment # 1**

CSE 324

Fall 2017

3a.	Instructions	: Exper	iment	1

Step 1: Connect into	the Network		
Establish and verify	connectivity to the Network.	This ensures the computer has	an IP address.
-	IP configuration information		
	to open the <b>Command Promp</b> for gathering the IP Configur	-	pe <b>ipconfig</b> and press the <b>Enter</b> key.
Step 3: Record the fo	ollowing TCP/IP information	n for your computer	
IP address:, Subnet Mask:, Default Gateway:		t Gateway:	
	<u> </u>	ur computer to another compucomputer B.Fill up the followi	
<u> </u>			Are there any similarities?  (yes/no)
IP Address:			,
Subnet Mask:			
<b>Default Gateway</b>			
To see detailed infor	onal TCP/IP configuration in mation, type ipconfig/all and	d press <b>Enter</b> .	

i. Does the output screen show any Servers?	
---	--

- ii. If yes, write down the IP addresses of the Servers listerd:
- iii. Write down the Host Name of your computer:.....
- iv. Write down the HostName of another computer:....
- v. Do all of the servers and workstations share the same network portion of the IP address as your pc?.....
- vi. If the servers and workstations are in another network, how to communicate with them?.....
- vii. Write down the Physical (MAC) Address of your computer:.....
- viii. Write down the Physical (MAC) Address of another computer:
- ix. Are there **any similarities** between them? If yes, **describe** the similarity in **1 sentence**......

#### Step 6: Close the screen

Close the screen when finished examining network settings. Repeat the previous steps as necessary. Make sure that it is possible to return to and interpret this screen.

#### 3b. Instructions: Experiment 2

You need the **IP addresses** that were recorded in **experiment 1**.

#### Step 1: Access the command prompt

Use the Start menu to open the Command Prompt window.

#### Step 2: ping the IP address of another computer

In the window, type <b>ping</b> , a space, and the <b>IP address of another computer B</b> . Is the <b>ping</b> successful
(yes/no) Note the results from the output screen:Packets: sent =, Received =, Lost =
Step 3: ping the IP address of the default gateway

Try to ping the IP address of the default gatewaylisted in the last exercise. Is the ping successful? (yes/no)\_ Note the results from the output screen: **Packets: sent =\_\_, Received = \_\_, Lost = \_** 

### Step 4: ping the Loopback IP address of this computer

Type the following command: ping 127.0.0.1 Is the ping successful? (yes/no)\_\_\_\_\_. Note the results from the output screen: Packets: sent =\_\_, Received = \_\_, Lost = \_

#### Step 5: ping the hostname of another computer

Try to ping the hostname of the computer B.Is the ping successful? (yes/no)\_\_\_\_\_. Note the results from the output screen: **Packets: sent =\_\_\_, Received = \_\_\_, Lost =**\_

#### Demonstrate your work to the instructors.

Signature of the Instructor